

List of obsolete switch part numbers (Catalog sales obsolete products)

<13AL> Illuminated SW (EOL series)	15GL-140-0010-E	8A2122-Z	8B2022-Z
13AL-060-0000-X	15GL-140-0030-E	8A3011C-Z	8B2041-Z
13AL-060-0010-X	15GL-140-0080-E	8A3012C-Z	8B2042-Z
13AL-060-0020-X	15GL-140-0160-E	8A3021-Z	8B2051-Z
13AL-060-0030-X	15GL-141-0000-E	8A3022C-Z	8B2052-Z
13AL-060-0040-X	15GL-141-0001-E	8A3022-Z	8B2061-Z
13AL-060-0050-X	15GL-141-0010-E	8A3041C-Z	8B2062-Z
13AL-090-0000-X	15GL-141-0030-E	8A3042C-Z	8B3012-Z
13AL-090-0010-X	15GL-141-0080-E	8A3042-Z	8B3021-Z
13AL-090-0020-X	15GL-141-0160-E	8A3051C-Z	8B3022-Z
13AL-090-0030-X	15GL-180-0000-E	8A3051-Z	8B4012-Z
13AL-090-0040-X	15GL-180-0001-E	8A3052C-Z	8B4021-Z
13AL-090-0050-X	15GL-180-0010-E	8A3052-Z	8B4022-Z
13AL-110-0000-X	15GL-180-0030-E	8A3061C-Z	<8C> Toggle SW
13AL-110-0010-X	15GL-180-0080-E	8A3061-Z	8C1011C-Z
13AL-110-0020-X	15GL-180-0160-E	8A3062C-Z	8C1012C-Z
13AL-110-0030-X	15GL-181-0000-E	8A3062-Z	8C1021C-Z
13AL-110-0040-X	15GL-181-0001-E	8A4011C-Z	8C1022-Z
13AL-110-0050-X	15GL-181-0010-E	8A4012C-Z	8C1041-Z
<13BL> Illuminated SW (EOL series)	15GL-181-0030-E	8A4012-Z	8C1042-Z
13BL-060-0000-X	15GL-181-0080-E	8A4021-Z	8C1051-Z
13BL-060-0010-X	15GL-181-0160-E	8A4022C-Z	8C1052-Z
13BL-060-0020-X	<8A> Toggle SW	8A4022C-Z	8C1061-Z
13BL-060-0030-X	8A1021C-Z	8A4041C-Z	8C1062-Z
13BL-060-0040-X	8A1041C-Z	8A4041-Z	8C2011C-Z
13BL-060-0050-X	8A1041-Z	8A4042C-Z	8C2012C-Z
13BL-090-0000-X	8A1042C-Z	8A4042-Z	8C2012-Z
13BL-090-0010-X	8A1042-Z	8A4051C-Z	8C2021C-Z
13BL-090-0020-X	8A1051C-Z	8A4051-Z	8C2022C-Z
13BL-090-0030-X	8A1051-Z	8A4052C-Z	8C2022-Z
13BL-090-0040-X	8A1052C-Z	8A4052-Z	8C2041-Z
13BL-090-0050-X	8A1052-Z	8A4061C-Z	8C2042-Z
13BL-110-0000-X	8A1061C-Z	8A4061-Z	8C2051-Z
13BL-110-0010-X	8A1061-Z	8A4062C-Z	8C2052-Z
13BL-110-0020-X	8A1062C-Z	8A4101C-Z	8C2061-Z
13BL-110-0030-X	8A1062-Z	8A4102C-Z	8C2062-Z
13BL-110-0040-X	8A2012C-Z	8A4102-Z	8C3012-Z
13BL-110-0050-X	8A2021C-Z	8A4111C-Z	8C3021-Z
<15EL> Illuminated SW (EOL series)	8A2022C-Z	8A4111-Z	8C3022-Z
15EL-122-0000-E	8A2041C-Z	8A4112C-Z	8C4011-Z
15EL-122-0010-E	8A2041-Z	8A4112-Z	8C4012-Z
15EL-122-0020-E	8A2042-Z	8A4121C-Z	8C4021-Z
15EL-122-0030-E	8A2051-Z	8A4121-Z	8C4022-Z
15EL-122-0040-E	8A2052C-Z	8A4122C-Z	<8D> Toggle SW (EOL series)
15EL-122-0050-E	8A2052-Z	8A4122-Z	8D1011C-Z
15EL-152-0000-E	8A2061C-Z	<8B> Toggle SW	8D1011-Z
15EL-152-0010-E	8A2061-Z	8B1011C-Z	8D1012C-Z
15EL-152-0020-E	8A2062C-Z	8B1012C-Z	8D1012-Z
15EL-152-0030-E	8A2062-Z	8B1021C-Z	8D1021C-Z
15EL-152-0040-E	8A2101C-Z	8B1022C-Z	8D1021-Z
15EL-152-0050-E	8A2101-Z	8B1022-Z	8D1022C-Z
15EL-182-0000-E	8A2102C-Z	8B1041-Z	8D1022-Z
15EL-182-0010-E	8A2102-Z	8B1042-Z	8D1041-Z
15EL-182-0020-E	8A2111C-Z	8B1051-Z	8D1042-Z
15EL-182-0030-E	8A2111-Z	8B1061-Z	8D1051-Z
15EL-182-0040-E	8A2112C-Z	8B1062-Z	8D1052-Z
15EL-182-0050-E	8A2112-Z	8B2011C-Z	8D1061-Z
<15GL> Illuminated SW (EOL series)	8A2121C-Z	8B2012C-Z	8D1062-Z
15GL-140-0000-E	8A2121-Z	8B2021C-Z	8D2011C-Z
15GL-140-0001-E	8A2122C-Z	8B2022C-Z	8D2011-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

8D2012C-Z	8F2021-Z	8G2062C-Z	8HD2052-Z
8D2012-Z	8F2022C-Z	8G2062-Z	8HD2061-Z
8D2021C-Z	8F2022-Z	8G2064C-Z	8HD2062-Z
8D2021-Z	8F2041-Z	8G2064-Z	<8J> Toggle SW
8D2022C-Z	8F2042-Z	8G2066C-Z	8J1011C-Z
8D2022-Z	8F2051-Z	8G2066-Z	8J1021C-Z
8D2041-Z	8F2052-Z	<8GA> Toggle SW	8J1022C-Z
8D2042-Z	8F2061-Z	8GA1022-Z	8J1041-Z
8D2051-Z	8F2062-Z	8GA1024-Z	8J1042-Z
8D2052-Z	8F3011-Z	8GA1026-Z	8J1051-Z
8D2061-Z	8F3012-Z	8GA2016-Z	8J1052-Z
8D2062-Z	8F3021-Z	8GA2022-Z	8J1061-Z
8D3011-Z	8F3022-Z	8GA2024-Z	8J1062-Z
8D3012-Z	8F4012-Z	8GA2026-Z	8J2011C-Z
8D3021-Z	8F4021-Z	<8GD> Toggle SW (EOL series)	8J2012C-Z
8D3022-Z	8F4022-Z	8GD1012-Z	8J2021C-Z
8D4011-Z	<8G> Toggle SW	8GD1014-Z	8J2022C-Z
8D4012-Z	8G1012C-Z	8GD1016-Z	8J2022-Z
8D4021-Z	8G1014C-Z	8GD1022-Z	8J2041-Z
8D4022-Z	8G1016C-Z	8GD1024-Z	8J2042-Z
<8E> Toggle SW	8G1022C-Z	8GD1026-Z	8J2051-Z
8E1012C-Z	8G1024C-Z	8GD2012-Z	8J2052-Z
8E1022C-Z	8G1026C-Z	8GD2014-Z	8J2061-Z
8E1022-Z	8G1026-Z	<8GS> Toggle SW (EOL series)	8J2062-Z
8E1041-Z	8G1042C-Z	8GS1012-Z	8J3011-Z
8E1042-Z	8G1044C-Z	8GS1014-Z	8J3022-Z
8E1051-Z	8G1044-Z	8GS1016-Z	8J4012-Z
8E1052-Z	8G1046C-Z	8GS2012-Z	8J4021-Z
8E1061-Z	8G1046-Z	8GS2014-Z	8J4022-Z
8E1062-Z	8G1052C-Z	8GS2016-Z	<8M> Lever&Rocker SW
8E2012-Z	8G1052-Z	<8H> Lever&Rocker SW	8M1011C-Z
8E2021C-Z	8G1054C-Z	8H1022-Z	8M1021C-Z
8E2022C-Z	8G1054-Z	8H1042-Z	8M1021-Z
8E2022-Z	8G1056C-Z	8H1051-Z	8M1041-Z
8E2041-Z	8G1056-Z	8H1052-Z	8M1051-Z
8E2042-Z	8G1062C-Z	8H1062-Z	8M1061-Z
8E2051-Z	8G1062-Z	8H2011C-Z	8M2011C-Z
8E2052-Z	8G1064C-Z	8H2021C-Z	8M2021C-Z
8E2061-Z	8G1066C-Z	8H2022-Z	8M2021-Z
8E2062-Z	8G1066-Z	8H2042-Z	8M2041-Z
8E3012-Z	8G2012C-Z	8H2051-Z	8M2051-Z
8E3021-Z	8G2014C-Z	8H2052-Z	8M2061-Z
8E3022-Z	8G2016C-Z	8H2061-Z	8M3021-Z
8E4012-Z	8G2022C-Z	<8HD> Lever&Rocker SW	8M4021-Z
8E4021-Z	8G2022-Z	8HD1011C-Z	<8N> Pushbutton SW
8E4022-Z	8G2024C-Z	8HD1012-Z	8N1011C-Z
<8F> Toggle SW	8G2024-Z	8HD1021C-Z	8N1012-Z
8F1012C-Z	8G2026C-Z	8HD1021-Z	8N2011C-Z
8F1021C-Z	8G2026-Z	8HD1022-Z	8N2021C-Z
8F1021-Z	8G2042C-Z	8HD1042-Z	<8P> Pushbutton SW
8F1022C-Z	8G2042-Z	8HD1051-Z	8P1012-Z
8F1022-Z	8G2044C-Z	8HD1052-Z	8P1022-Z
8F1041-Z	8G2044-Z	8HD1061-Z	8P2012-Z
8F1042-Z	8G2046C-Z	8HD1062-Z	8P2022-Z
8F1051-Z	8G2046-Z	8HD2011C-Z	8P3011-Z
8F1052-Z	8G2052C-Z	8HD2012-Z	8P3021-Z
8F1061-Z	8G2052-Z	8HD2021C-Z	8P4011-Z
8F1062-Z	8G2054C-Z	8HD2022-Z	8P4021-Z
8F2011C-Z	8G2054-Z	8HD2041-Z	<8Q> Lever&Rocker SW (EOL series)
8F2012C-Z	8G2056C-Z	8HD2042-Z	8Q1011-Z
8F2021C-Z	8G2056-Z	8HD2051-Z	8Q1021C-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

8Q1021-Z	8SS2012C-Z	AP2L-6M-Z	ATE1H-2J3-10-Z
8Q1041-Z	8SS2022C-Z	AP2L-6S-Z	ATE1H-6F3-10-Z
8Q1051-Z	<8V-M> Lever&Rocker SW	AP2M-2H-Z	ATE1H-6J3-10-Z
8Q1061-Z	8V1012C-M-Z	AP2M-2M-Z	ATE1H-7F3-10-Z
8Q2011C-Z	8V1022C-M-Z	AP2M-2S-Z	ATE1H-7J3-10-Z
8Q2011-Z	8V1022-M-Z	AP2M-6S-Z	ATE1H-7M3-10-Z
8Q2021C-Z	8V1042-M-Z	AP2R-2H-Z	ATE2D-2J3-10-Z
8Q2021-Z	8V1052-M-Z	AP2R-2S-Z	ATE2D-6J3-10-Z
8Q2041-Z	8V2022C-M-Z	AP2R-2S-Z	ATE2D-7F3-10-Z
8Q2051-Z	8V2022-M-Z	<APE> Pushbutton SW	ATE2D-7J3-10-Z
8Q2061-Z	8V2042-M-Z	APE2F-5M-10-Z	ATE2D-7M3-10-Z
8Q3011-Z	8V2052-M-Z	<AS> Slide SW	ATE2E-2F3-10-Z
8Q3021-Z	<8V-Q> Lever&Rocker SW (EOL series)	AS1E-6M-10-Z	ATE2E-2J3-10-Z
8Q4011-Z	8V1012-Q-Z	AS2E-2M-10-Z	ATE2E-5F3-10-Z
8Q4021-Z	8V1022-Q-Z	AS2E-5M-10-Z	ATE2E-5M3-10-Z
<8R> Pushbutton SW	8V1042-Q-Z	AS2E-6M-10-Z	ATE2E-6F3-10-Z
8R1011B-N-Z	8V1052-Q-Z	AS2P-2M-10-Z	ATE2E-6J3-10-Z
8R1012B-N-Z	8V1062-Q-Z	AS2P-5M-10-Z	ATE2E-6M3-10-Z
8R1012-N-Z	8V2012-Q-Z	AS2P-6M-10-Z	ATE2E-7F3-10-Z
8R2011B-N-Z	8V2022-Q-Z	<ASE> Slide SW	ATE2E-7J3-10-Z
8R2012B-N-Z	8V2042-Q-Z	ASE1E-5M-10-Z	ATE2E-7M3-10-Z
8R2012-N-Z	<8W> Pushbutton SW	ASE1E-6M-10-Z	ATE2F-2F3-10-Z
<8S> Toggle SW	8W1011-N-Z	ASE2E-5M-10-Z	ATE2F-2J3-10-Z
8S1011C-Z	8W1021B-N-Z	ASE2E-6M-10-Z	ATE2F-5F3-10-Z
8S1011-Z	8W1022-N-Z	ASE2N-5M-10-Z	ATE2F-5M3-10-Z
8S1012-Z	8W2011-N-Z	ASE2P-2M-10-Z	ATE2F-6F3-10-Z
8S1021C-Z	8W2021B-N-Z	ASE2P-5M-10-Z	ATE2F-6J3-10-Z
8S1021-Z	8W2022B-N-Z	ASE2P-6M-10-Z	ATE2F-6M3-10-Z
8S1022-Z	8W2022-N-Z	<ATE> Toggle SW	ATE2F-7F3-10-Z
8S1041-Z	<8Y> Pushbutton SW	ATE1D-2J3-10-Z	ATE2F-7J3-10-Z
8S1042-Z	8Y4011-Z	ATE1D-5F3-10-Z	ATE2F-7M3-10-Z
8S1051-Z	8Y4012-Z	ATE1D-6F3-10-Z	ATE2G-2J3-10-Z
8S1052-Z	<ALE> Lever&Rocker SW	ATE1D-6J3-10-Z	ATE2G-5F3-10-Z
8S1061-Z	ALE1E-5M4-10-Z	ATE1D-7F3-10-Z	ATE2G-6F3-10-Z
8S1062-Z	ALE1F-5M4-10-Z	ATE1D-7F3-10-Z	ATE2G-6J3-10-Z
8S2011C-Z	ALE1G-5M4-10-Z	ATE1D-7J3-10-Z	ATE2G-6M3-10-Z
8S2011-Z	ALE1H-2M4-10-Z	ATE1D-7M3-10-Z	ATE2G-7F3-10-Z
8S2012-Z	ALE1H-5M4-10-Z	ATE1E-2J3-10-Z	ATE2G-7J3-10-Z
8S2021C-Z	ALE2E-2M4-10-Z	ATE1E-5F3-10-Z	ATE2G-7M3-10-Z
8S2021-Z	ALE2E-5M4-10-Z	ATE1E-6F3-10-Z	ATE2H-2F3-10-Z
8S2022-Z	ALE2F-2M4-10-Z	ATE1E-6J3-10-Z	ATE2H-2J3-10-Z
8S2041-Z	ALE2F-5M4-10-Z	ATE1E-7F3-10-Z	ATE2H-2M3-10-Z
8S2042-Z	ALE2G-2M4-10-Z	ATE1E-7J3-10-Z	ATE2H-5F3-10-Z
8S2051-Z	ALE2G-5M4-10-Z	ATE1E-7M3-10-Z	ATE2H-5M3-10-Z
8S2052-Z	ALE2H-2M4-10-Z	ATE1F-2F3-10-Z	ATE2H-6F3-10-Z
8S2061-Z	ALE2H-5M4-10-Z	ATE1F-2J3-10-Z	ATE2H-6J3-10-Z
8S2062-Z	ALE2N-2M4-10-Z	ATE1F-5F3-10-Z	ATE2H-6M3-10-Z
8S3011-Z	ALE2P-2M4-10-Z	ATE1F-5M3-10-Z	ATE2H-7F3-10-Z
8S3012-Z	ALE2R-2M4-10-Z	ATE1F-6F3-10-Z	ATE2H-7J3-10-Z
8S3021-Z	ALE2S-2M4-10-Z	ATE1F-6J3-10-Z	ATE2H-7M3-10-Z
8S3022-Z	ALE2T-2M4-10-Z	ATE1F-7J3-10-Z	ATE2N-2F3-10-Z
8S4011-Z	<AP> Pushbutton SW	ATE1F-7M3-10-Z	ATE2N-2M3-10-Z
8S4012-Z	AP1B-2H-Z	ATE1G-2F3-10-Z	ATE2N-5F3-10-Z
8S4021-Z	AP1B-2M-Z	ATE1G-2J3-10-Z	ATE2N-5M3-10-Z
8S4022-Z	AP1B-2S-Z	ATE1G-6F3-10-Z	ATE2N-6F3-10-Z
<8SS> Slide SW	AP1B-6M-Z	ATE1G-6J3-10-Z	ATE2N-6M3-10-Z
8SS1011C-Z	AP1B-6S-Z	ATE1G-7F3-10-Z	ATE2P-2F3-10-Z
8SS1012C-Z	AP2L-2H-Z	ATE1G-7J3-10-Z	ATE2P-2M3-10-Z
8SS1022C-Z	AP2L-2M-Z	ATE1G-7M3-10-Z	ATE2P-5F3-10-Z
8SS2011C-Z	AP2L-2S-Z	ATE1H-2F3-10-Z	ATE2P-5M3-10-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

ATE2P-6M3-10-Z	CF-LA-1AC4-6C	CF-LA-2KL-4C	ATE2P-6F3-10-Z
ATE2R-2F3-10-Z	CF-LA-1AC-4C	CF-LA-2KL-5	CFPB-1CC-3O2W
ATE2R-2M3-10-Z	CF-LA-1AC-5	CF-LA-2KL-5C	CFPB-1CC-3O6W
ATE2R-5F3-10-Z	CF-LA-1AC-5C	CF-LA-2KL-6	CFPB-1CC-3O9W
ATE2R-5M3-10-Z	CF-LA-1AC-6	CF-LA-2KL-6C	CFPB-1CC-4W1W
ATE2R-6F3-10-Z	CF-LA-1AC-6C	CF-LA-2KZ2-1	CFPB-1CC-4W2W
ATE2R-6M3-10-Z	CF-LA-1AL-3C	CF-LA-2KZ2-2C	CFPB-1CC-4W6W
ATE2S-2F3-10-Z	CF-LA-1AL-4	CF-LA-2KZ2-4	CFPB-1CC-4W9W
ATE2S-2M3-10-Z	CF-LA-1AL-4C	CF-LA-2KZ2-4C	CFPB-1CC-5B1W
ATE2S-5F3-10-Z	CF-LA-1AL-5	CF-LA-2KZ2-6	CFPB-1CC-5B2W
ATE2S-5M3-10-Z	CF-LA-1AL-5C	CF-LA-2KZ2-6C	CFPB-1CC-5B6W
ATE2S-6F3-10-Z	CF-LA-1AL-6	<CF-LD> Lever SW	CFPB-1CC-5B9W
ATE2S-6M3-10-Z	CF-LA-1AL-6C	CF-LD- 1 DC4-AG2	CFPB-1CC-5G1W
ATE2T-2F3-10-Z	CF-LA-1AZ2-2	CF-LD- 1 DC4-AG2W	CFPB-1CC-5G2W
ATE2T-2M3-10-Z	CF-LA-1AZ2-2C	CF-LD- 1 DC4-AR2	CFPB-1CC-5G6W
ATE2T-5F3-10-Z	CF-LA-1AZ2-4	CF-LD- 1 DC4-AR2W	CFPB-1CC-5G9W
ATE2T-5M3-10-Z	CF-LA-1AZ2-4C	CF-LD- 1 DC4-AW2	CFPB-1CC-5Y1W
ATE2T-6F3-10-Z	CF-LA-1AZ2-5	CF-LD- 1 DC4-AW2W	CFPB-1CC-5Y2W
ATE2T-6M3-10-Z	CF-LA-1AZ2-5C	CF-LD- 1 DC6-AG2	CFPB-1CC-5Y6W
<ATE4/ATLE4>> Toggle SW	CF-LA-1AZ2-6	CF-LD- 1 DC6-AG2W	CFPB-1CC-5Y9W
ATE42D-2M3-Z	CF-LA-1AZ2-6C	CF-LD- 1 DC6-AR2	<CFT2> Toggle SW
ATE42E-2M4-Z	CF-LA-2KC-1	CF-LD- 1 DC6-AR2W	CFT2-1FC4-AW
ATE42E-2M3-Z	CF-LA-2KC-1C	CF-LD- 1 DC6-AW2	CFT2-1FC6-AW
ATE44D-2M3-Z	CF-LA-2KC-2	CF-LD- 1 DC6-AW2W	CFT2-1FC-AW
ATLE2N-5M3-Z	CF-LA-2KC-2C	CF-LD- 1 DC-AG2	CFT2-2NC4-AW
ATLE42D-6M3-Z	CF-LA-2KC-3	CF-LD- 1 DC-AG2W	CFT2-2NC6-AW
ATLE42E-2M3-Z	CF-LA-2KC-4	CF-LD- 1 DC-AR2	CFT2-2NC-AW
ATLE42E-6M3-Z	CF-LA-2KC4-1	CF-LD- 1 DC-AR2W	CFT2-2PC4-AW
ATLE44D-2M3-Z	CF-LA-2KC4-1C	CF-LD- 1 DC-AW2	CFT2-2PC6-AW
ATLE44D-2M4-Z	CF-LA-2KC4-2	CF-LD- 1 DC-AW2W	CFT2-2PC-AW
ATLE44E-2M3-Z	CF-LA-2KC4-2C	<CFPB> Illuminated SW	CFT2-2RC4-AW
ATLE44E-2M4-Z	CF-LA-2KC4-3	CFPB-1CC-1B1W	CFT2-2RC6-AW
<BT> Toggle SW (EOL series)	CF-LA-2KC4-3C	CFPB-1CC-1B2W	CFT2-2RC-AW
BT1D-2M4-Z	CF-LA-2KC4-4	CFPB-1CC-1B6W	CFT2-2SC4-AW
BT1E-2M4-Z	CF-LA-2KC4-4C	CFPB-1CC-1B9W	CFT2-2SC6-AW
BT1F-2M4-Z	CF-LA-2KC4-5	CFPB-1CC-1G1W	CFT2-2SC-AW
BT1G-2M4-Z	CF-LA-2KC4-5C	CFPB-1CC-1G2W	CFT2-2TC4-AW
BT1H-2M4-Z	CF-LA-2KC4-6	CFPB-1CC-1G6W	CFT2-2TC6-AW
BT2N-2M4-Z	CF-LA-2KC4-6C	CFPB-1CC-1G9W	CFT2-2TC-AW
BT2P-2M4-Z	CF-LA-2KC-4C	CFPB-1CC-1O1W	<CL-LB> Rocker SW
BT2R-2M4-Z	CF-LA-2KC5-1	CFPB-1CC-1O2W	CL-LB-11A1-S00-21A0-0-000
BT2S-2M4-Z	CF-LA-2KC5-1C	CFPB-1CC-1O6W	CL-LB-11B1-S00-21A0-0-000
BT2T-2M4-Z	CF-LA-2KC5-2	CFPB-1CC-1O9W	<CLP44> Illuminated SW (EOL series)
<CF-LA> Rocker SW	CF-LA-2KC5-2C	CFPB-1CC-1R1W	CLP44-L2
CF-LA-1AC-1	CF-LA-2KC5-3	CFPB-1CC-1R2W	CLP44-L25
CF-LA-1AC-1C	CF-LA-2KC5-4	CFPB-1CC-1R6W	CLP44-L26
CF-LA-1AC-2	CF-LA-2KC5-4C	CFPB-1CC-1R9W	<DP> Pushbutton SW
CF-LA-1AC-2C	CF-LA-2KC5-5	CFPB-1CC-1W1W	DP2-100-B-Z
CF-LA-1AC-3	CF-LA-2KC5-5C	CFPB-1CC-1W2W	DP2-100-M-Z
CF-LA-1AC-3C	CF-LA-2KC5-6	CFPB-1CC-1W6W	DP2-100-O-Z
CF-LA-1AC-4	CF-LA-2KC5-6C	CFPB-1CC-1W9W	DP2-100-R-Z
CF-LA-1AC4-1	CF-LA-2KC-5C	CFPB-1CC-1Y1W	DP2-101B-BL2-Z
CF-LA-1AC4-1C	CF-LA-2KC-6	CFPB-1CC-1Y2W	DP2-101B-GL2-Z
CF-LA-1AC4-2	CF-LA-2KC-6C	CFPB-1CC-1Y6W	DP2-101-BL2-Z
CF-LA-1AC4-2C	CF-LA-2KL-1	CFPB-1CC-1Y9W	DP2-101-BL5-Z
CF-LA-1AC4-4	CF-LA-2KL-2	CFPB-1CC-2R1W	DP2-101-BL8-Z
CF-LA-1AC4-4C	CF-LA-2KL-2C	CFPB-1CC-2R2W	DP2-101-GL2-Z
CF-LA-1AC4-5	CF-LA-2KL-3	CFPB-1CC-2R6W	DP2-101-GL5-Z
CF-LA-1AC4-5C	CF-LA-2KL-3C	CFPB-1CC-2R9W	DP2-101-GL8-Z
CF-LA-1AC4-6	CF-LA-2KL-4	CFPB-1CC-3O1W	DP2-101-KL2-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

DP2-101-KL5-Z	EL125E-Z	ET115E-Z	ET225P10-Z
DP2-101-KL8-Z	EL210R-Z	ET115F10-Z	ET225P10-Z
DP2-101-OL2-Z	EL215K12-Z	ET115F12-Z	ET310A-Z
DP2-101-OL5-Z	EL215K-Z	ET115G10-Z	ET310D-Z
DP2-101-OL8-Z	EL215N12-Z	ET115H10-Z	ET310E-Z
DP2-101-RL2-Z	EL215N-Z	ET120D12-Z	ET315A12-Z
DP2-101-RL5-Z	EL215P12-Z	ET120F10-Z	ET315F12-Z
DP2-101-RL8-Z	EL215P-Z	ET120F12-Z	ET315G12-Z
DP2-101-WL2-Z	EL225K12-Z	ET120F-Z	ET315H12-Z
DP2-101-WL5-Z	EL225K-14-Z	ET120G10-Z	ET325A12-Z
DP2-101-WL8-Z	EL225K-15-Z	ET120G12-Z	ET325D12-Z
DP2-101-YL2-Z	EL225K-Z	ET120G-Z	ET325E12-Z
DP2-102-BL22-Z	EL225N12-Z	ET120H10-Z	ET330A12-Z
DP2-102-BL25-Z	EL225N-Z	ET120H12-Z	ET330A-Z
DP2-102-GL22-Z	EL225P-Z	ET125A-Z	ET330D12-Z
DP2-102-GL25-Z	ELE115A-Z	ET125D10-Z	ET330E12-Z
DP2-102-GL88-Z	ELE115D-Z	ET125D-Z	ET410K12-Z
DP2-102-KL25-Z	ELE115E-Z	ET125E10-Z	ET410N12-Z
DP2-102-ML25-Z	ELE125A-Z	ET125E12-Z	ET410P12-Z
DP2-102-OL25-Z	ELE125D-Z	ET205K12-Z	ET410R12-Z
DP2-102-RL25-Z	ELE125E-Z	ET205N12-Z	ET410R13-Z
DP2-102-WL25-Z	ELE215K12-Z	ET205P12-Z	ET410S12-Z
DP2-110-B-Z	ELE215K-Z	ET206K12-Z	ET410T12-Z
DP2-110-G-Z	ELE215N-Z	ET206N12-Z	ET415K12-Z
DP2-110-K-Z	ELE225K12-Z	ET210K-Z	ET415K13-Z
DP2-110-O-Z	ELE225K-Z	ET210N10-Z	ET415N12-Z
DP2-110-R-Z	ELE225N12-Z	ET210N-Z	ET415N13-Z
DP2-110-W-Z	ELE225N-Z	ET210P10-Z	ET415P12-Z
DP2-111-BL2-Z	<ES> Slide SW	ET210P-Z	ET415P13-Z
DP2-111-BL5-Z	ES115E12-Z	ET210R10-Z	ET420K12-Z
DP2-111-GL2-Z	ES125A-Z	ET210R12-Z	ET420K13-Z
DP2-111-GL5-Z	ES125D10-Z	ET210R-Z	ET420N12-Z
DP2-111-KL2-Z	ES125D-Z	ET210S10-Z	ET420N13-Z
DP2-111-KL5-Z	ES125E12-Z	ET210S12-Z	ET420P12-Z
DP2-111-ML5-Z	ES125E-Z	ET210S-Z	ET420P13-Z
DP2-111-OL2-Z	ES215K12-Z	ET210T10-Z	ET425P12-Z
DP2-111-OL5-Z	ES215K-Z	ET210T12-Z	<FL> Lever&Rocker SW
DP2-111-OL8-Z	ES215N10-Z	ET210T-Z	FL1E-5M-Z
DP2-111-RL2-Z	ES215N12-Z	ET215K-Z	FL1F-2M-Z
DP2-111-RL5-Z	ES215P12-Z	ET215L10-Z	FL1FA-5M-Z
DP2-111-WL2-Z	ES225K12-Z	ET215L12-Z	FL1G-2M-Z
DP2-111-YL2-Z	ES225N10-Z	ET215M10-Z	FL1G-5M-Z
DP3-101B-L5-Z	ES225N-Z	ET215P10-Z	FL1H-2M-Z
DP3-101-L2-Z	ES225P-Z	ET215R10-Z	FL1H-5M-Z
DP3-101-L5-Z	<ET> Toggle SW	ET215R12-Z	FL1HA-5M-Z
DP3-101-L8-Z	ET103A12-Z	ET215S10-Z	FL2D-2M-Z
DPL4-200B-Z	ET103A32-Z	ET215T10-Z	FL2D-5M-Z
DPL4-200-Z	ET103V12-Z	ET215T12-Z	FL2E-2M-Z
<EL/ELE> Rocker SW (EOL series)	ET103V32-Z	ET220M12-Z	FL2E-5M-Z
EL110G-Z	ET110F12-Z	ET220P12-Z	FL2F-2M-Z
EL115A12-Z	ET110G10-Z	ET220R10-Z	FL2F-5M-Z
EL115D12-Z	ET110G12-Z	ET220R12-Z	FL2FA-5M-Z
EL115D-Z	ET110G-Z	ET220R-Z	FL2G-2M-Z
EL115E12-Z	ET110H10-Z	ET220S12-Z	FL2G-5M-Z
EL115E-Z	ET110H12-Z	ET220T10-Z	FL2H-2M-Z
EL120G-Z	ET110H-Z	ET220T12-Z	FL2H-5M-Z
EL125A12-Z	ET115B12-Z	ET220T-Z	FL2HA-5M-Z
EL125A-Z	ET115C10-Z	ET225K10-Z	<FT> Toggle SW
EL125D12-Z	ET115D10-Z	ET225N10-Z	FT1F-4M-Z
EL125D-Z	ET115E10-Z	ET225N-Z	FT1F-5M-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

FT1FA-4M-Z	LP1S-16S-505-Z	LP1W-16G-505-Z	LP1W-27S-209-Z
FT1FA-5M-Z	LP1S-16S-509-Z	LP1W-16G-509-Z	LP1W-27S-229-Z
FT1G-4M-Z	LP1S-16S-559-Z	LP1W-16G-559-Z	LP1W-27S-505-Z
FT1G-5M-Z	LP1S-16S-808-Z	LP1W-16G-808-Z	LP1W-27S-509-Z
FT1H-2M-Z	LP1S-16S-809-Z	LP1W-16G-809-Z	LP1W-27S-559-Z
FT1H-4M-Z	LP1S-16S-889-Z	LP1W-16G-889-Z	LP1W-27S-808-Z
FT1H-5M-Z	LP1S-17G-202-Z	LP1W-16S-202-Z	LP1W-27S-809-Z
FT1HA-4M-Z	LP1S-17G-209-Z	LP1W-16S-209-Z	LP1W-27S-889-Z
FT1HA-5M-Z	LP1S-17G-229-Z	LP1W-16S-229-Z	LP2S-16G-202-Z
FT2E-4M-Z	LP1S-17G-505-Z	LP1W-16S-505-Z	LP2S-16G-209-Z
FT2E-5M-Z	LP1S-17G-509-Z	LP1W-16S-509-Z	LP2S-16G-229-Z
FT2F-2M-Z	LP1S-17G-559-Z	LP1W-16S-808-Z	LP2S-16G-509-Z
FT2F-4M-Z	LP1S-17G-808-Z	LP1W-16S-809-Z	LP2S-16G-559-Z
FT2F-5M-Z	LP1S-17G-809-Z	LP1W-16S-889-Z	LP2S-16G-808-Z
FT2FA-4M-Z	LP1S-17G-889-Z	LP1W-17G-202-Z	LP2S-16G-809-Z
FT2FA-5M-Z	LP1S-17S-202-Z	LP1W-17G-209-Z	LP2S-16G-889-Z
FT2G-4M-Z	LP1S-17S-209-Z	LP1W-17G-229-Z	LP2S-16S-202-Z
FT2G-5M-Z	LP1S-17S-229-Z	LP1W-17G-505-Z	LP2S-16S-209-Z
FT2H-2M-Z	LP1S-17S-505-Z	LP1W-17G-509-Z	LP2S-16S-229-Z
FT2H-4M-Z	LP1S-17S-509-Z	LP1W-17G-559-Z	LP2S-16S-505-Z
FT2H-5M-Z	LP1S-17S-559-Z	LP1W-17G-808-Z	LP2S-16S-509-Z
FT2HA-4M-Z	LP1S-17S-808-Z	LP1W-17G-809-Z	LP2S-16S-559-Z
FT2HA-5M-Z	LP1S-17S-809-Z	LP1W-17G-889-Z	LP2S-16S-808-Z
<HLA> Rocker SW (EOL series)	LP1S-17S-889-Z	LP1W-17S-202-Z	LP2S-16S-809-Z
HLA112A	LP1S-26G-202-Z	LP1W-17S-209-Z	LP2S-16S-889-Z
HLA112A12	LP1S-26G-209-Z	LP1W-17S-229-Z	LP2S-17G-202-Z
HLA112D	LP1S-26G-229-Z	LP1W-17S-505-Z	LP2S-17G-209-Z
HLA112D12	LP1S-26G-509-Z	LP1W-17S-509-Z	LP2S-17G-229-Z
HLA208K	LP1S-26G-559-Z	LP1W-17S-559-Z	LP2S-17G-505-Z
HLA208K12	LP1S-26G-808-Z	LP1W-17S-808-Z	LP2S-17G-509-Z
HLA208N	LP1S-26G-809-Z	LP1W-17S-809-Z	LP2S-17G-559-Z
HLA208N12	LP1S-26G-889-Z	LP1W-17S-889-Z	LP2S-17G-808-Z
<HLC> Rocker SW (EOL series)	LP1S-26S-202-Z	LP1W-26G-202-Z	LP2S-17G-809-Z
HLC112A	LP1S-26S-209-Z	LP1W-26G-209-Z	LP2S-17G-889-Z
HLC112A12	LP1S-26S-229-Z	LP1W-26G-229-Z	LP2S-17S-202-Z
HLC112D	LP1S-26S-505-Z	LP1W-26G-505-Z	LP2S-17S-209-Z
HLC112D12	LP1S-26S-509-Z	LP1W-26G-509-Z	LP2S-17S-229-Z
HLC208K	LP1S-26S-559-Z	LP1W-26G-559-Z	LP2S-17S-505-Z
HLC208K12	LP1S-26S-808-Z	LP1W-26G-808-Z	LP2S-17S-509-Z
HLC208N	LP1S-26S-809-Z	LP1W-26G-809-Z	LP2S-17S-559-Z
HLC208N12	LP1S-26S-889-Z	LP1W-26G-889-Z	LP2S-17S-808-Z
<HSS> Slide SW (EOL series)	LP1S-27G-202-Z	LP1W-26S-202-Z	LP2S-17S-809-Z
HSS112A	LP1S-27G-505-Z	LP1W-26S-209-Z	LP2S-17S-889-Z
HSS112A12	LP1S-27G-509-Z	LP1W-26S-229-Z	LP2S-26G-209-Z
HSS112D	LP1S-27G-559-Z	LP1W-26S-505-Z	LP2S-26G-505-Z
HSS112D12	LP1S-27G-808-Z	LP1W-26S-509-Z	LP2S-26G-509-Z
HSS208K	LP1S-27G-809-Z	LP1W-26S-559-Z	LP2S-26G-559-Z
HSS208K12	LP1S-27G-889-Z	LP1W-26S-808-Z	LP2S-26G-808-Z
HSS208N	LP1S-27S-202-Z	LP1W-26S-809-Z	LP2S-26G-809-Z
HSS208N12	LP1S-27S-209-Z	LP1W-26S-889-Z	LP2S-26G-889-Z
<LP> Illuminated SW	LP1S-27S-229-Z	LP1W-27G-202-Z	LP2S-26S-202-Z
LP1S-16G-209-Z	LP1S-27S-505-Z	LP1W-27G-209-Z	LP2S-26S-209-Z
LP1S-16G-229-Z	LP1S-27S-509-Z	LP1W-27G-229-Z	LP2S-26S-229-Z
LP1S-16G-505-Z	LP1S-27S-559-Z	LP1W-27G-505-Z	LP2S-26S-505-Z
LP1S-16G-559-Z	LP1S-27S-808-Z	LP1W-27G-509-Z	LP2S-26S-509-Z
LP1S-16G-808-Z	LP1S-27S-809-Z	LP1W-27G-559-Z	LP2S-26S-559-Z
LP1S-16G-889-Z	LP1S-27S-889-Z	LP1W-27G-808-Z	LP2S-26S-808-Z
LP1S-16S-202-Z	LP1W-16G-202-Z	LP1W-27G-809-Z	LP2S-26S-809-Z
LP1S-16S-209-Z	LP1W-16G-209-Z	LP1W-27G-889-Z	LP2S-26S-889-Z
LP1S-16S-229-Z	LP1W-16G-229-Z	LP1W-27S-202-Z	LP2S-27G-202-Z

List of obsolete switch part numbers (Catalog sales obsolete products)

LP2S-27G-209-Z	LP2W-26G-889-Z	MCS222N-2016	MRK1031G-Z
LP2S-27G-229-Z	LP2W-26S-202-Z	MCS222N-2018	MRK1031H-R-Z
LP2S-27G-505-Z	LP2W-26S-209-Z	MCS231PA-1011	MRK1031H-Z
LP2S-27G-559-Z	LP2W-26S-229-Z	MCS232PA-1012	MRK1031K-R-Z
LP2S-27G-808-Z	LP2W-26S-505-Z	MCS232PA-1013	MRK1031K-Z
LP2S-27G-809-Z	LP2W-26S-509-Z	MCS421N-1014	MRK1031L-R-Z
LP2S-27G-889-Z	LP2W-26S-559-Z	MCS421N-2031	MRK1041D-R-Z
LP2S-27S-202-Z	LP2W-26S-808-Z	MCS421N-2033	MRK1041D-Z
LP2S-27S-209-Z	LP2W-26S-809-Z	MCS422N-1015	MRK2012A-R-Z
LP2S-27S-229-Z	LP2W-26S-889-Z	MCS422N-2009	MRK2012A-Z
LP2S-27S-505-Z	LP2W-27G-202-Z	MCS422N-2030	MRK2012B-R-Z
LP2S-27S-509-Z	LP2W-27G-209-Z	MCS422N-2032	MRK2012B-Z
LP2S-27S-559-Z	LP2W-27G-229-Z	MCS431PA-2010	MRK2012C-R-Z
LP2S-27S-808-Z	LP2W-27G-505-Z	MCS442NN-1016	MRK2012C-Z
LP2S-27S-809-Z	LP2W-27G-509-Z	MCS622N-2011	MRK2022B-R-Z
LP2S-27S-889-Z	LP2W-27G-559-Z	<MFS> Slide SW	MRK2022B-Z
LP2W-16G-202-Z	LP2W-27G-808-Z	MFS101D-11-Z	MRK2031D-R-Z
LP2W-16G-209-Z	LP2W-27G-809-Z	MFS101D-15-Z	MRK2031E-R-Z
LP2W-16G-229-Z	LP2W-27G-889-Z	<MHS> Slide SW (EOL series)	MRK2031E-Z
LP2W-16G-505-Z	LP2W-27S-202-Z	MHS121	MRK2031F-R-Z
LP2W-16G-509-Z	LP2W-27S-209-Z	MHS122	MRK2031F-Z
LP2W-16G-559-Z	LP2W-27S-229-Z	MHS122-1	MRK2031G-R-Z
LP2W-16G-808-Z	LP2W-27S-505-Z	MHS131	MRK2031G-Z
LP2W-16G-809-Z	LP2W-27S-509-Z	MHS132	MRK2031H-R-Z
LP2W-16G-889-Z	LP2W-27S-559-Z	MHS221	MRK2031H-Z
LP2W-16S-202-Z	LP2W-27S-808-Z	MHS222	MRK2031K-R-Z
LP2W-16S-209-Z	LP2W-27S-809-Z	MHS231	MRK2031K-Z
LP2W-16S-229-Z	LP2W-27S-889-Z	MHS232	MRK2031L-R-Z
LP2W-16S-505-Z	<LTM/LTR> Illuminated SW	MHS422	MRK2031L-Z
LP2W-16S-509-Z	LTM2-01-L6	<MR> Rotary SW	MRK2041D-R-Z
LP2W-16S-559-Z	LTMG2-01-L6	MR1-12-Z	<MRKC> Key SW (EOL series)
LP2W-16S-808-Z	LTR2-01-L6	MR2-6G-Z	MRKC1012A-01-Z
LP2W-16S-809-Z	<LTM3-01> Illuminated SW (EOL series)	MR2-6-Z	MRKC1012A-R-01-Z
LP2W-16S-889-Z	LTM3-01-L2C-Z	MR3-3G-Z	MRKC1031L-01-Z
LP2W-17G-202-Z	LTM3-01-L2R-Z	MR3-3-Z	MRKC1031L-R-01-Z
LP2W-17G-209-Z	LTM3-01-L5C-Z	MR3-4G-Z	MRKC1033D-R-01-Z
LP2W-17G-229-Z	LTM3-01-L5M-Z	MR3-4-Z	MRKC1041L-01B-Z
LP2W-17G-505-Z	LTM3-01-L8C-Z	MR4-3-Z	MRKC1041L-01-Z
LP2W-17G-509-Z	LTM3-01-L8Y-Z	<MRE> Rotary SW (EOL series)	MRKC1052B-C-10
LP2W-17G-559-Z	LTMG3-01-L2C-Z	MRE1-10G-Z	<MRKS> Key SW (EOL series)
LP2W-17G-808-Z	LTMG3-01-L2R-Z	MRE1-10-Z	MRKS1051N-R-Z
LP2W-17G-809-Z	LTMG3-01-L5C-Z	MRE2-5G-Z	MRKS1051N-Z
LP2W-17G-889-Z	LTMG3-01-L5M-Z	MRE2-5-Z	<MRP> Pulse SW (EOL series)
LP2W-17S-202-Z	LTMG3-01-L8C-Z	MRE3-3G-Z	MRP1-20-1-Z
LP2W-17S-209-Z	LTMG3-01-L8Y-Z	MRE3-3-Z	MRP1-20-R-Z
LP2W-17S-229-Z	<MCS> Slide SW (EOL series)	MRE4-2G-Z	<MSP> Pushbutton SW
LP2W-17S-505-Z	MCS122D-1002	MRE4-2-Z	MSP103BG-Z
LP2W-17S-509-Z	MCS122D-2001	<MRK> Key SW	MSP103CG-Z
LP2W-17S-559-Z	MCS131EA-1004	MRK1012B-R-Z	<MTS> Slide SW (EOL series)
LP2W-17S-808-Z	MCS132EA-1005	MRK1012C-R-Z	MTS124
LP2W-17S-809-Z	MCS221N-1006	MRK1012C-Z	MTS134
LP2W-17S-889-Z	MCS221N-1007	MRK1022B-R-Z	<S> Slide SW (EOL series)
LP2W-26G-202-Z	MCS221N-1008	MRK1022B-Z	S-1-Z
LP2W-26G-209-Z	MCS221N-2017	MRK1031D-R-Z	S-2-Z
LP2W-26G-229-Z	MCS222N-1009	MRK1031D-Z	S-3-Z
LP2W-26G-505-Z	MCS222N-1010	MRK1031E-R-Z	S-4-Z
LP2W-26G-509-Z	MCS222N-2002	MRK1031E-Z	<SL220SD> Lever SW (EOL series)
LP2W-26G-559-Z	MCS222N-2003	MRK1031F-R-Z	SL220SD-15-Z
LP2W-26G-808-Z	MCS222N-2004	MRK1031F-Z	<SLA215K> Rocker SW (EOL series)
LP2W-26G-809-Z	MCS222N-2005	MRK1031G-R-Z	SLA215K

List of obsolete switch part numbers (Catalog sales obsolete products)

SLA215K-5	SLE6A2-8	SP210L-Z	TR3-21-L02
SLA215K-6	SLE6A4	SP210M-Z	TR3-21-L05
SLA215K-7	SLE6A4-50	SP210N-Z	TR3-21-L08
<SLE10> Rocker SW	SLE6A4-8	SP210R-Z	TR3-21-L2
SLE10A2	SLE6A4-9	<S2P> Pushbutton SW (EOL series)	TR3-21-L202
SLE10A2-8	SLE6A5	S2P210K-Z	TR3-21-L205
SLE10A2-9	SLE6A-50	S2P210N-Z	TR3-21-L208
SLE10A4	SLE6A5-50	S2P210P-Z	TR3-21-L5
SLE10A4-5	SLE6A5-7	<SPP> Pushbutton SW (EOL series)	TR3-21-L502
SLE10A4-6	SLE6A5-8	SPP203KA-Z	TR3-21-L505
SLE10A4-7	SLE6A5-9	SPP203K-Z	TR3-21-L508
SLE10A4-8	SLE6A-8	SPP203N-Z	TR3-21-L8
SLE10A4-9	SLE6D	SPP210KA-Z	TR3-21-L805
SLE10A-5	SLE6D2	SPP210K-Z	TR3-21-L808
SLE10A5-5	SLE6D2-5	SPP210N-Z	<TME> Tactile SW
SLE10A5-6	SLE6D2-50	<SS> Slide SW (EOL series)	TMEG1-01-Z
SLE10A5-7	SLE6D2-6	SS110A-Z	<SG> Tigger SW (EOL)
SLE10A5-8	SLE6D2-7	SS110D-Z	SGE106CV-A-Z
SLE10A5-9	SLE6D2-8	SS110E-Z	SGE108CV-A-Z
SLE10A-8	SLE6D2-9	SS210K-Z	SGE108CV-Z
SLE10A-9	SLE6D4	SS210N-Z	SGE110F
SLE10D	SLE6D4-5	SS210P-Z	SGE110F-A
SLE10D2	SLE6D4-50	SS220K-23-Z	SGE110FR
SLE10D2-5	SLE6D4-6	<STE> Toggle SW (EOL series)	SGE115F-A-Z
SLE10D2-6	SLE6D4-7	STE115D10-Z	SGEL106CV-A-Z
SLE10D2-7	SLE6D4-8	<TM/TR> Illuminated SW	SGEL106CVR-A-Z
SLE10D2-8	SLE6D4-9	TM2-21-L6	SGEL108CV-A-Z
SLE10D2-9	SLE6D5	TM3-21-L002	SGEL115CDY-1-Z
SLE10D4	SLE6D-5	TM3-21-L005	SGEL115F-A-Z
SLE10D4-5	SLE6D-50	TM3-21-L008	
SLE10D4-6	SLE6D5-5	TM3-21-L02	
SLE10D4-7	SLE6D5-50	TM3-21-L05	
SLE10D4-8	SLE6D5-6	TM3-21-L08	
SLE10D4-9	SLE6D5-7	TM3-21-L2	
SLE10D5	SLE6D5-8	TM3-21-L202	
SLE10D-5	SLE6D5-9	TM3-21-L205	
SLE10D5-5	SLE6D-6	TM3-21-L208	
SLE10D5-6	SLE6D-7	TM3-21-L5	
SLE10D5-7	SLE6D-8	TM3-21-L502	
SLE10D5-8	SLE6D-9	TM3-21-L505	
SLE10D5-9	<SMAP> Pushbutton SW	TM3-21-L508	
SLE10D-6	SMAP2F-2M-Z	TM3-21-L8	
SLE10D-7	SMAP2F-5M-E-Z	TM3-21-L802	
SLE10D-8	SMAP2F-5M-Z	TM3-21-L805	
SLE10D-9	<SP101> Pushbutton SW	TM3-21-L808	
<SLE210K> Rocker SW	SP101F	TMG2-21-L6	
SLE210K11	SP101F-P	TMG3-21-L005	
SLE210K11-5	<SPC103> Pushbutton SW (EOL series)	TMG3-21-L08	
SLE210K11-7	SPC103F	TMG3-21-L2	
SLE210K11-9	SPC103F-C	TMG3-21-L202	
SLE210K4-5	SPC103F-P	TMG3-21-L205	
SLE210K4-7	<SP> Pushbutton SW (EOL series)	TMG3-21-L208	
SLE210K4-9	SP103AB-Z	TMG3-21-L5	
SLE210K9	SP103B-Z	TMG3-21-L502	
SLE210K9-5	SP103C-Z	TMG3-21-L505	
SLE210K9-6	SP103V-Z	TMG3-21-L8	
SLE210K9-7	SP110AC-Z	TR2-21-L6	
SLE210K9-9	SP110A-Z	TR3-21-L002	
<SLE6> Rocker SW	SP110D-Z	TR3-21-L005	
SLE6A2-50	SP210K-Z	TR3-21-L008	

List of obsolete switch accessory (Catalog sales obsolete products)

Accessory number	Switch series	Switch name	Accessory name	Remark
14000050429	8M · 8V-M	Lever&Rocker SW	Lever	Black
14000050441	8Q · 8V-Q	Lever&Rocker SW	Lever	White
14000050442	8Q · 8V-Q	Lever&Rocker SW	Lever	Red
14000050443	8Q · 8V-Q	Lever&Rocker SW	Lever	Black
14000050444	8Q · 8V-Q	Lever&Rocker SW	Lever	Gray
14000050511	8H	Lever&Rocker SW	Lever	White
14000050512	8H	Lever&Rocker SW	Lever	Red
14000050513	8H	Lever&Rocker SW	Lever	Black
14000050514	8H	Lever&Rocker SW	Lever	Gray
14000050627	ALE	Lever&Rocker SW	Lever	Yellow
14000050628	ALE	Lever&Rocker SW	Lever	Green
14000050629	ALE	Lever&Rocker SW	Lever	Green
14000050632	ALE	Lever&Rocker SW	Lever	Orange
14000050647	ALE	Lever&Rocker SW	Lever	Green
14000050694	8H	Lever&Rocker SW	Lever	Red
14000050696	8H	Lever&Rocker SW	Lever	Gray
14000050859	FL	Lever&Rocker SW	Lever	Red
14000050884	ATE-2J · 6J · 7J	Toggle SW	Color Cap	White
14000050885	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Black
14000050886	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Red
14000050887	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Yellow
14000050888	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Green
14000050889	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Green
14000050890	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Gray
14000050891	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Green
14000050892	ATE-2J · 6J · 7J	Toggle SW	Color Cap	Orange
14000050929	8M · 8V-M	Lever&Rocker SW	Lever	White
14000050930	8M · 8V-M	Lever&Rocker SW	Lever	Red
14000050931	8M · 8V-M	Lever&Rocker SW	Lever	Black
14000050932	8M · 8V-M	Lever&Rocker SW	Lever	Gray
14000260715	8A · 8C · 8D · 8J · 8S	Toggle SW	Bracket	1, 2 poles
14000340128	8A · 8C · 8D · 8J · 8S	Toggle SW	Bracket	1, 2 poles
14000340150	TM1 · TM2 · TR1 · TR2	Illuminated SW	Mounting Frame	Ivory
14000340154	TR1 · TR3	Illuminated SW	Mounting Frame	Ivory
14000340156	DP4 · DPL4	Push button SW	Mounting Frame	White
14000340158	DP4 · DPL4	Push button SW	Mounting Frame	Red
14000340184	LTR · LTM	Illuminated SW	Mounting Frame	Ivory
14000340190	TP · TPL	Illuminated SW	Mounting Frame	Ivory
14000340198	TP · TPL	Illuminated SW	Mounting Frame	Ivory
14000340218	TM1 · TM3	Illuminated SW	Mounting Frame	Ivory
140000470039	BT · 8A · 8F · 8GA	Toggle SW	Color Cap	Black
140000470057	8Y	Push button SW	Color Cap	Gray
140000470061	8E	Toggle SW	Color Cap	Red
140000470102	8B	Toggle SW	Color Cap	Gray
140000470112	8S · 8GS	Toggle SW	Color Tip	Black
140000470118	8S · 8GS	Toggle SW	Color Tip	White
140000470119	8S · 8GS	Toggle SW	Color Tip	Red
140000470120	8S · 8GS	Toggle SW	Color Tip	Gray
140000470161	DP1-100-Z · DP3-101-Z	Push button SW	Color Cap	Orange
140000470176	ATE-2M · 5M · 6M · 7M	Toggle SW	Color Cap	Yellow
140000470177	ATE-2M · 5M · 6M · 7M	Toggle SW	Color Cap	Green
140000470178	ATE-2M · 5M · 6M · 7M	Toggle SW	Color Cap	Green
140000470180	ATE-2M · 5M · 6M · 7M	Toggle SW	Color Cap	Green
140000470181	ATE-2M · 5M · 6M · 7M	Toggle SW	Color Cap	Orange
140000470186	DP1-100-Z · DP3-101-Z	Push button SW	Color Cap	Yellow
140000470192	DP1-120-Z	Push button SW	Color Cap	Orange
140000470201	AP-H	Push button SW	Color button	Yellow
140000470202	AP-H	Push button SW	Color button	Green
140000470203	AP-H	Push button SW	Color button	Green
140000470205	AP-H	Push button SW	Color button	Orange
140000470206	AP-H	Push button SW	Color button	Green
140000470218	DP1-120-Z	Push button SW	Color Cap	Yellow
140000470234	ATLE	Toggle SW	Color Cap	Red
140000470259	ATLE	Toggle SW	Color Cap	Green
140000470260	ATLE	Toggle SW	Color Cap	Black
140000470383	ATLE	Toggle SW	Color Cap	Black
140000480085	8N · 8P · 8R	Push button SW	Color button	Green
140000480086	8N · 8P · 8R	Push button SW	Color button	Green
140000480087	8N · 8P · 8R	Push button SW	Color button	Orange
140000480092	8N · 8P · 8R	Push button SW	Color button	Green
140000480093	8N · 8P · 8R	Push button SW	Color button	Green
140000480094	8N · 8P · 8R	Push button SW	Color button	Orange
140000480335	8H	Lever&Rocker SW	Rocker	Gray
140000480371	8N · 8P · 8R	Push button SW	Color button	Yellow

List of obsolete switch accessory (Catalog sales obsolete products)

Accessory number	Switch series	Switch name	Accessory name	Remark
140000480372	8N · 8P · 8R	Push button SW	Color button	Yellow
140000480522	8M · 8V-M	Lever&Rocker SW	Rocker	Gray
140000480524	8Q · 8V-Q	Lever&Rocker SW	Rocker	White
140000480525	8Q · 8V-Q	Lever&Rocker SW	Rocker	Red
140000480526	8Q · 8V-Q	Lever&Rocker SW	Rocker	Black
140000480527	8Q · 8V-Q	Lever&Rocker SW	Rocker	Gray
140000480630	HLC · HLS	Rocker SW	Color button	Yellow
140000480633	HLC · HLS	Rocker SW	Color button	Green
140000480676	ALE	Lever&Rocker SW	Rocker	Yellow
140000480677	ALE	Lever&Rocker SW	Rocker	Green
140000480678	ALE	Lever&Rocker SW	Rocker	Green
140000480679	ALE	Lever&Rocker SW	Rocker	Gray
140000480680	ALE	Lever&Rocker SW	Rocker	Orange
140000480685	HLC · HLS	Rocker SW	Rocker	Black
140000480686	HLC · HLS	Rocker SW	Rocker	Red
140000480687	HLC · HLS	Rocker SW	Rocker	Gray-
140000480688	HLC · HLS	Rocker SW	Rocker	Green-
140000480689	HLC · HLS	Rocker SW	Rocker	Green-
140000480690	HLC · HLS	Rocker SW	Rocker	Yellow-
140000480691	HLC · HLS	Rocker SW	Rocker	Green-
140000480693	ALE	Lever&Rocker SW	Rocker	Green
140000480711	HLC · HLS	Rocker SW	Rocker	Red-White
140000480739	HLC · HLS	Rocker SW	Color button	White-
140000480741	HLC · HLS	Rocker SW	Color button	Gray-White
140000480747	TR1 · TM1	Illuminated SW	Color button	Green
140000480751	TR1 · TM1	Illuminated SW	Color button	Green
140000480752	TR1 · TM1	Rocker SW	Color button	Red
140000480753	TR1 · TM1	Rocker SW	Color button	Green
140000480754	TR1 · TM1	Rocker SW	Color button	Green
140000480755	TR1 · TM1	Rocker SW	Color button	Green
140000480766	TR1 · TM1	Rocker SW	Color button	Silver
140000480800	HLC · HLS	Rocker SW	Color button	Gray-Red
140000480865	HLC · HLS	Rocker SW	Color button	Gray-Black
140000480896	HLC · HLS	Rocker SW	Color button	Red-Black
140000481301	TR3 · TM3	Illuminated SW	Color button	Dark Gray
140000481302	TR3 · TM3	Rocker SW	Color button	Dark Gray
140000481330	TR3 · TM3	Rocker SW	Color button	Gray
140000481331	TR3 · TM3	Illuminated SW	Color button	Light Gray
140000481332	TR3 · TM3	Illuminated SW	Color button	Ivory
140000481333	TR3 · TM3	Illuminated SW	Color button	Red
140000481334	TR3 · TM3	Illuminated SW	Color button	Green
140000481335	TR3 · TM3	Illuminated SW	Color button	Green
140000481336	TR3 · TM3	Illuminated SW	Color button	Green
140000481337	TR3 · TM3	Illuminated SW	Color button	Gray
140000481338	TR3 · TM3	Illuminated SW	Color button	Light Gray
140000481339	TR3 · TM3	Illuminated SW	Color button	Ivory
140000481340	TR3 · TM3	Illuminated SW	Color button	Red
140000481341	TR3 · TM3	Illuminated SW	Color button	Green
140000481342	TR3 · TM3	Illuminated SW	Color button	Green
140000481343	TR3 · TM3	Illuminated SW	Color button	Green
140000481405	AP-M · APE-M · AP-S	Push button SW	Color Cap	Yellow
140000481406	AP-M · APE-M · AP-S	Push button SW	Color Cap	Green
140000481407	AP-M · APE-M · AP-S	Push button SW	Color Cap	Green
140000481409	AP-M · APE-M · AP-S	Push button SW	Color Cap	Green
140000481411	FL	Lever&Rocker SW	Rocker	Red
140000481413	FL	Lever&Rocker SW	Rocker	Gray
140000481414	AP-M · APE-M · AP-S	Push button SW	Color Cap	Orange
140000481424	8N · 8P · 8R	Push button SW	Color button	Green
140000481425	8N · 8P · 8R	Push button SW	Color button	Green
140000481426	8N · 8P · 8R	Push button SW	Color button	Orange
140000481427	8N · 8P · 8R	Push button SW	Color button	Yellow
140000481511	HLC · HLS	Rocker SW	Color button	Yellow-White
140000481531	8M · 8V-M	Lever&Rocker SW	Rocker	White
140000481532	8M · 8V-M	Lever&Rocker SW	Rocker	Red
140000481533	8M · 8V-M	Lever&Rocker SW	Rocker	Black
140000481534	8M · 8V-M	Lever&Rocker SW	Rocker	Gray
140000481541	ATE-2J · 6J · 7J	Toggle SW	Rocker	White
140000481542	ATE-2J · 6J · 7J	Toggle SW	Rocker	Black
140000481543	ATE-2J · 6J · 7J	Toggle SW	Rocker	Red
140000481544	ATE-2J · 6J · 7J	Toggle SW	Rocker	Yellow
140000481545	ATE-2J · 6J · 7J	Toggle SW	Rocker	Green
140000481546	ATE-2J · 6J · 7J	Toggle SW	Rocker	Green
140000481547	ATE-2J · 6J · 7J	Toggle SW	Rocker	Gray
140000481548	ATE-2J · 6J · 7J	Toggle SW	Rocker	Green

List of obsolete switch accessory (Catalog sales obsolete products)

Accessory number	Switch series	Switch name	Accessory name	Remark
140000481549	ATE-2J · 6J · 7J	Toggle SW	Rocker	Orange
140000481595	FL	Lever&Rocker SW	Rocker	Red
140000481596	FL	Lever&Rocker SW	Rocker	Black
140000481691	SP103	Push button SW	Color button	White
140000481692	SP103	Push button SW	Color button	Red
140000481693	SP103	Push button SW	Color button	Black
140000481694	SP103	Push button SW	Color button	Gray
140000481695	SP103	Push button SW	Color button	Green
140000481696	SP103	Push button SW	Color button	Green
140000481697	SP103	Push button SW	Color button	Orange
140000481698	SP103	Push button SW	Color button	Yellow
140000481699	SP103	Push button SW	Color button	White
140000481700	SP103	Push button SW	Color button	Red
140000481701	SP103	Push button SW	Color button	Black
140000481702	SP103	Push button SW	Color button	Gray
140000481703	SP103	Push button SW	Color button	Green
140000481704	SP103	Push button SW	Color button	Green
140000481705	SP103	Push button SW	Color button	Orange
140000481706	SP103	Push button SW	Color button	Yellow
140000610111	MRE(36°Step)	Rotary SW	O-RING	Nitril rubber-Black
140000640296	ATE-2J	Toggle SW	Bracket	Box size 5.6mm
140000640316	AP-S	Push button SW	Bracket	Box size 5mm
140000640317	AP-S	Push button SW	Bracket	Box size 7.5mm
140007250012	LP2S	Illuminated SW	Switch Guard	21×24.6×6.8mm
140007480072	TR2 · TM2	Illuminated SW	Color button	Red
140007480073	TR2 · TM2	Illuminated SW	Color button	Green
140007480074	TR2 · TM2	Illuminated SW	Color button	Green
140007480075	TR2 · TM2	Illuminated SW	Color button	Green
140007480085	TR2 · TM2	Illuminated SW	Color button	Silver
140007480086	TR3 · TM3	Illuminated SW	Color button	Dark Gray
140007480087	TR3 · TM3	Illuminated SW	Color button	Gray
140007480088	TR3 · TM3	Illuminated SW	Color button	Light Gray
140007480089	TR3 · TM3	Illuminated SW	Color button	Ivory
140007480090	TR3 · TM3	Illuminated SW	Color button	Red
140007480091	TR3 · TM3	Illuminated SW	Color button	Green
140007480092	TR3 · TM3	Illuminated SW	Color button	Green
140007480093	TR3 · TM3	Illuminated SW	Color button	Green
140007480094	TR3 · TM3	Illuminated SW	Color button	Silver
140007480103	TR3 · TM3	Illuminated SW	Color button	Silver
140007480104	TR3 · TM3	Illuminated SW	Color button	Dark Gray
140007480105	TR3 · TM3	Illuminated SW	Color button	Gray
140007480106	TR3 · TM3	Illuminated SW	Color button	Light Gray
140007480107	TR3 · TM3	Illuminated SW	Color button	Ivory
140007480108	TR3 · TM3	Illuminated SW	Color button	Red
140007480109	TR3 · TM3	Illuminated SW	Color button	Green
140007480110	TR3 · TM3	Illuminated SW	Color button	Green
140007480111	TR3 · TM3	Illuminated SW	Color button	Green
140007480112	TR3 · TM3	Illuminated SW	Color button	Silver
140007480121	TR2 · TM2	Illuminated SW	Color button	Red
140007480122	TR2 · TM2	Illuminated SW	Color button	Green
140007480123	TR2 · TM2	Illuminated SW	Color button	Green
140007480124	TR2 · TM2	Illuminated SW	Color button	Green
140007480182	LTR · LTM	Illuminated SW	Color button	Red
140007480183	LTR · LTM	Illuminated SW	Color button	Green
140007480184	LTR · LTM	Illuminated SW	Color button	Green
140007480201	LTR · LTM	Illuminated SW	Color button	Ivory
140007480204	LTR · LTM	Illuminated SW	Color button	Green
140007480210	LTR · LTM	Illuminated SW	Color button	Yellow clear
140007480216	LTR · LTM	Illuminated SW	Color button	Yellow clear
140007480232	TP · TPL	Illuminated SW	Color button	Green
140007480233	TP · TPL	Illuminated SW	Color button	Green
140007480242	TP · TPL	Illuminated SW	Color button	Green
140007480243	TP · TPL	Illuminated SW	Color button	Green
140007480248	TP · TPL	Illuminated SW	Color button	Red
140007480249	TP · TPL	Illuminated SW	Color button	Green
140007480250	TP · TPL	Illuminated SW	Color button	Green
140007480251	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480252	TP · TPL	Illuminated SW	Color button	Gray
140007480253	TP · TPL	Illuminated SW	Color button	White
140007480254	TP · TPL	Illuminated SW	Color button	Ivory
140007480255	TP · TPL	Illuminated SW	Color button	Red
140007480256	TP · TPL	Illuminated SW	Color button	Green
140007480257	TP · TPL	Illuminated SW	Color button	Green
140007480258	TP · TPL	Illuminated SW	Color button	Dark Gray

List of obsolete switch accessory (Catalog sales obsolete products)

Accessory number	Switch series	Switch name	Accessory name	Remark
140007480259	TP · TPL	Illuminated SW	Color button	Gray
140007480260	TP · TPL	Illuminated SW	Color button	White
140007480261	TP · TPL	Illuminated SW	Color button	Ivory
140007480262	TP · TPL	Illuminated SW	Color button	Red
140007480263	TP · TPL	Illuminated SW	Color button	Green
140007480264	TP · TPL	Illuminated SW	Color button	Green
140007480265	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480266	TP · TPL	Illuminated SW	Color button	Gray
140007480267	TP · TPL	Illuminated SW	Color button	White
140007480268	TP · TPL	Illuminated SW	Color button	Ivory
140007480270	TP · TPL	Illuminated SW	Color button	Green
140007480271	TP · TPL	Illuminated SW	Color button	Green
140007480275	TP · TPL	Illuminated SW	Color button	Ivory
140007480280	TP · TPL	Illuminated SW	Color button	Green
140007480281	TP · TPL	Illuminated SW	Color button	Green
140007480286	TP · TPL	Illuminated SW	Color button	Red
140007480287	TP · TPL	Illuminated SW	Color button	Green
140007480288	TP · TPL	Illuminated SW	Color button	Green
140007480289	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480290	TP · TPL	Illuminated SW	Color button	Gray
140007480291	TP · TPL	Illuminated SW	Color button	White
140007480292	TP · TPL	Illuminated SW	Color button	Ivory
140007480293	TP · TPL	Illuminated SW	Color button	Red
140007480294	TP · TPL	Illuminated SW	Color button	Green
140007480295	TP · TPL	Illuminated SW	Color button	Green
140007480296	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480297	TP · TPL	Illuminated SW	Color button	Gray
140007480298	TP · TPL	Illuminated SW	Color button	White
140007480299	TP · TPL	Illuminated SW	Color button	Ivory
140007480300	TP · TPL	Illuminated SW	Color button	Red
140007480301	TP · TPL	Illuminated SW	Color button	Green
140007480302	TP · TPL	Illuminated SW	Color button	Green
140007480303	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480304	TP · TPL	Illuminated SW	Color button	Gray
140007480305	TP · TPL	Illuminated SW	Color button	White
140007480306	TP · TPL	Illuminated SW	Color button	Ivory
140007480452	LTR · LTM	Illuminated SW	Color button	Dark Gray
140007480455	LTR · LTM	Illuminated SW	Color button	Ivory
140007480456	LTR · LTM	Illuminated SW	Color button	Red
140007480457	LTR · LTM	Illuminated SW	Color button	Green
140007480458	LTR · LTM	Illuminated SW	Color button	Green
140007480462	LTR · LTM	Illuminated SW	Color button	Ivory
140007480463	LTR · LTM	Illuminated SW	Color button	Red
140007480464	LTR · LTM	Illuminated SW	Color button	Green
140007480465	LTR · LTM	Illuminated SW	Color button	Green
140007480468	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480469	TP · TPL	Illuminated SW	Color button	Gray
140007480470	TP · TPL	Illuminated SW	Color button	White
140007480471	TP · TPL	Illuminated SW	Color button	Ivory
140007480472	TP · TPL	Illuminated SW	Color button	Red
140007480473	TP · TPL	Illuminated SW	Color button	Green
140007480474	TP · TPL	Illuminated SW	Color button	Green
140007480475	TP · TPL	Illuminated SW	Color button	Dark Gray
140007480476	TP · TPL	Illuminated SW	Color button	Gray
140007480477	TP · TPL	Illuminated SW	Color button	White
140007480478	TP · TPL	Illuminated SW	Color button	Ivory
140007480479	TP · TPL	Illuminated SW	Color button	Red
140007480480	TP · TPL	Illuminated SW	Color button	Green
140007480481	TP · TPL	Illuminated SW	Color button	Green
140007480551	LTR · LTM	Illuminated SW	Color button	Red clear
140007480555	LTR · LTM	Illuminated SW	Color button	Red clear
140007480556	LTR · LTM	Illuminated SW	Color button	Green clear
140007480557	LTR · LTM	Illuminated SW	Color button	Yellow clear
140007480558	LTR · LTM	Illuminated SW	Color button	Clear
140007480559	LTR · LTM	Illuminated SW	Color button	Red clear
140007480562	LTR · LTM	Illuminated SW	Color button	Clear
140007480563	LTR · LTM	Illuminated SW	Color button	Red clear
140007480564	LTR · LTM	Illuminated SW	Color button	Green clear
140007480565	LTR · LTM	Illuminated SW	Color button	Yellow clear
140007480566	LTR · LTM	Illuminated SW	Color button	Clear
140007480567	LTR · LTM	Illuminated SW	Color button	Dark Gray
140007480568	LTR · LTM	Illuminated SW	Color button	Gray
140007480569	8B · 8Y	Illuminated SW	Color button	Light Gray
140007480570	LTR · LTM	Illuminated SW	Color button	Ivory

List of obsolete switch accessory (Catalog sales obsolete products)

Accessory number	Switch series	Switch name	Accessory name	Remark
140007480571	LTR · LTM	Illuminated SW	Color button	Red
140007480572	LTR · LTM	Illuminated SW	Color button	Green
140007480573	8A · 8C · 8E · 8J · 8N · 8R	Illuminated SW	Color button	Green
140007480574	LTR · LTM	Illuminated SW	Color button	Dark Gray
140007480575	LTR · LTM	Illuminated SW	Color button	Gray
140007480576	LTR · LTM	Illuminated SW	Color button	Light Gray
140007480577	LTR · LTM	Illuminated SW	Color button	Ivory
140007480578	LTR · LTM	Illuminated SW	Color button	Red
140007480579	LTR · LTM	Illuminated SW	Color button	Green
140007480580	LTR · LTM	Illuminated SW	Color button	Green
140008010236	SP210 · SPP · S2P	Push button SW	Nut	Tin-cobalt plated
140008010238	ET	Toggle SW	Nut	Chromium plated
140008010258	8A · 8C · 8D · 8E · 8J · 8N · 8S · 8R	Toggle SW	Nut	Chromium plated
140008010272	8B · 8Y	Toggle SW	Nut	Chromium plated
140008010273	8B · 8Y	Toggle SW	Nut	Chromium plated
140008010274	8A · 8C · 8D · 8E · 8J · 8N · 8S · 8R	Toggle SW	Nut	Nickel plated
140008010276	8A · 8C · 8D · 8E · 8J · 8N · 8S · 8R	Toggle SW	Nut	Nickel plated
140008050104	DP4 · DPL4	Push button SW	Color button	Black
140008050109	DP4 · DPL4	Push button SW	Color button	Gray
140008050153	SP · SPP · S2P	Push button SW	Color button	Black
140008050155	SP · SPP · S2P	Push button SW	Color button	Red
140008050156	SPP	Push button SW	Color button	Black
140008050157	SPP	Push button SW	Color button	Red
140008050158	SP · SPP · S2P	Push button SW	Color button	White
140008050162	SP · SPP · S2P	Push button SW	Color button	White
140008050163	SP · SPP · S2P	Push button SW	Color button	Black
140008050164	SP · SPP · S2P	Push button SW	Color button	Red
140008050165	SP · SPP · S2P	Push button SW	Color button	Gray
140008150123	MRP1-20-1	Rotary SW	Washer	
140009002602	MRKC	Key SW	Key	Grip material-Metal
140009003061	MRKC	Key SW	Key	Grip material-Plastic
140009003423	MRKC1052B-C-10	Key SW	Key	Grip material-Metal